

**Handling Manual**  
**for**  
**HV 4.8 CONNECTOR 2P FEMALE**  
**(SHORT TERMINAL VERSION)**

**<NOTE>**

Please be informed that the contents in this handling manual  
may be revised without notice.





YAZAKI (CHINA) INVESTMENT CO.,LTD  
SEPT. 16. 2019

This handling manual mentions the minimum items necessary on using this product.  
Please observe these written contents when handling.  
YAZAKI shall not be liable for any damages resulting from misuse or failure to follow this manual.


## Table of Contents

|                                                            |       |           |
|------------------------------------------------------------|-------|-----------|
| 1. Components part list                                    | ..... | P.3 ~ P.4 |
| 2. Manufacturing process and inspection precautions        |       |           |
| No. 1 Rear Holder and Rubber to Wire Installation          | ..... | P.5       |
| No. 2 Wire Insulation Stripping                            | ..... | P.6       |
| No. 3 Wire Sheath and Braided Shield Stripping             | ..... | P.7       |
| No. 4 Shield Terminal and Shield Pipe Installation         | ..... | P.8       |
| No. 5 Shield Terminal and Shield Pipe Crimping             | ..... | P.9       |
| No. 6 Power Terminal Crimping                              | ..... | P.10      |
| No. 7 Power Terminal Installation and Front Holder Setting | ..... | P.11      |
| No. 8 Rubber and Rear Holder Installation                  | ..... | P.12      |
| 3. The size of Insertion Tool                              | ..... | P.13      |
| 4. Power Terminal Removal and Precautions                  | ..... |           |
| No. 1 Front Holder Full-lock Removal                       | ..... | P.14      |
| No. 2 Terminal Removal                                     | ..... | P.15      |


## 1. Components Part List

| No. | Part Name                                             | Part No                                      | Image Form                                                                            | Function                                               |
|-----|-------------------------------------------------------|----------------------------------------------|---------------------------------------------------------------------------------------|--------------------------------------------------------|
| 1   | HV 4.8 CONNECTOR 2P<br>HOUSING FEMALE<br>SUB ASSEMBLY | 7285-1207-51<br>7285-1208-51<br>7285-1209-51 |    | TERMINAL RETENTION<br>SHIELD GROUND                    |
| 2   | HV 4.8 CONNECTOR 2P<br>TERMINAL FEMALE                | 7185-0906-02                                 |    | CONNECTION OF ELECTRIC CIRCUIT                         |
| 3   | HV 4.8 CONNECTOR 2P<br>SHIELD TERMINAL                | 7185-0903-03<br>7185-0805-03                 |    | CONNECTION BETWEEN SHIELD SHELL<br>AND BRAIDED WIRE    |
| 4   | HV 4.8 CONNECTOR 2P<br>SHIELD PIPE                    | 7185-0807<br>7185-0806                       |   | CONNECTION BETWEEN SHIELD TERMINAL<br>AND BRAIDED WIRE |
| 5   | HV 4.8 CONNECTOR 2P<br>RUBBER                         | 7172-5730-80<br>7172-5731-30                 |  | SEALING FOR TERMINALS                                  |


1. Components Part List

| No. | Part Name                          | Part No                   | Image Form                                                                          | Function                       |
|-----|------------------------------------|---------------------------|-------------------------------------------------------------------------------------|--------------------------------|
| 6   | HV 4.8 CONNECTOR 2P<br>REAR HOLDER | 7185-0799<br>7185-0801-51 |  | PREVENTS RUBBER FROM DETACHING |
|     |                                    |                           |                                                                                     |                                |
|     |                                    |                           |                                                                                     |                                |
|     |                                    |                           |                                                                                     |                                |
|     |                                    |                           |                                                                                     |                                |


## 2. Manufacturing process and inspection precautions

| No.               | 1                                                                                                                                                                                                   | REAR HOLDER and RUBBER to wire Installation |
|-------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------|
| Production Method |                                                                                                                   |                                             |
| Part Name         | REAR HOLDER, RUBBER, Power Wire                                                                                                                                                                     |                                             |
| Equipment         | -                                                                                                                                                                                                   |                                             |
| Standard          | -                                                                                                                                                                                                   |                                             |
| Inspection Matter | <ul style="list-style-type: none"> <li>• There shall be no dust and other foreign object on the rubber.</li> <li>• There shall be no damage or scratch on the sealing surface of rubber.</li> </ul> |                                             |
| Precautions       | <ul style="list-style-type: none"> <li>• Care must be taken not to damage the seal surface during wire insertion, Damage on the sealing surface can lead to product malfunction.</li> </ul>         |                                             |


## 2. Manufacturing process and inspection precautions

| No.               | 2                                                                                                                                    | WIRE Insulation Stripping |
|-------------------|--------------------------------------------------------------------------------------------------------------------------------------|---------------------------|
| Production Method |  <p>5.45mm(REF)</p> <p>Power Wire<br/>Figure 1</p> |                           |
| Part Name         | Power Wire                                                                                                                           |                           |
| Equipment         | Stripping tools                                                                                                                      |                           |
| Standard          | Insulation Strip dimension:<br>・ Power : 5.45mm (Refer to figure 1)                                                                  |                           |
| Inspection Matter | ・ Insulation strip must be free from any damage.                                                                                     |                           |
| Precautions       | ・ Damage in wire strip can cause increase in crimp resistance which may lead to product malfunction.                                 |                           |


## 2. Manufacturing process and inspection precautions

| No.               | 3                                                                                                                                                                       | WIRE Sheath and Braided Stripping |
|-------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------|
| Production Method |  <p>Figure 2</p>                                                                      |                                   |
| Part Name         | Power Wire                                                                                                                                                              |                                   |
| Equipment         | Stripping tools                                                                                                                                                         |                                   |
| Standard          | <ul style="list-style-type: none"> <li>• Insulation Strip dimension: 9.30mm (Refer to figure 2)</li> <li>• Braided shield length: 5.00mm (Refer to figure 2)</li> </ul> |                                   |
| Inspection Matter | <ul style="list-style-type: none"> <li>• Insulation and braided shield strip must be free from any damage.</li> </ul>                                                   |                                   |
| Precautions       | <ul style="list-style-type: none"> <li>• Damage in wire strip can cause increase in crimp resistance which may lead to product malfunction.</li> </ul>                  |                                   |


## 2. Manufacturing process and inspection precautions

| No.               | 4                                                                                                                                                     | SHIELD TERMINAL and SHIELD PIPE Installation |
|-------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------|
| Production Method |  <p>Figure 3</p>                                                    |                                              |
| Part Name         | SHIELD TERMINAL, SHIELD PIPE                                                                                                                          |                                              |
| Equipment         | Crimping Machine                                                                                                                                      |                                              |
| Standard          | Shield Crimping Standard (Refer to YGT19-0054)                                                                                                        |                                              |
| Inspection Matter | <ul style="list-style-type: none"> <li>Braided shield must be properly bended between shield terminal and shield pipe. (Refer to figure 3)</li> </ul> |                                              |
| Precautions       | <ul style="list-style-type: none"> <li>Care must be taken not to damage the braided shield, damage may cause product malfunction.</li> </ul>          |                                              |

## 2. Manufacturing process and inspection precautions


| No.               | 5                                                                                                                                                    | SHIELD TERMINAL and SHIELD PIPE Crimping |
|-------------------|------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------|
| Production Method |  <p>Figure 4</p>                                                   |                                          |
| Part Name         | SHIELD TERMINAL, SHIELD PIPE                                                                                                                         |                                          |
| Equipment         | Crimping Machine                                                                                                                                     |                                          |
| Standard          | <ul style="list-style-type: none"> <li>Dimension from the tip of the shield terminal to the tip of conductor: 21.20mm (Refer to figure 4)</li> </ul> |                                          |
| Inspection Matter | <ul style="list-style-type: none"> <li>There shall be no protruded braided wire.</li> <li>There shall be no burr on shield pipe crimped.</li> </ul>  |                                          |
| Precautions       | <ul style="list-style-type: none"> <li>Care must be taken not to damage the rubber and rear holder during crimping process.</li> </ul>               |                                          |

## 2. Manufacturing process and inspection precautions

| No.               | 6                                                                                                                                                                                                                                                              | POWER TERMINAL Crimping |
|-------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------|
| Production Method |                                                                                                                                                                              |                         |
| Part Name         | TERMINAL FEMALE                                                                                                                                                                                                                                                |                         |
| Equipment         | Crimping Machine                                                                                                                                                                                                                                               |                         |
| Standard          | Crimping Standard (Refer to YGT19-0054)                                                                                                                                                                                                                        |                         |
| Inspection Matter | <ul style="list-style-type: none"> <li>• After crimping there should be no damage on the terminal female.</li> <li>• No burr after crimping.</li> <li>• No deformation after crimping.</li> </ul>                                                              |                         |
| Precautions       | <ul style="list-style-type: none"> <li>• Care must be taken not to damage the rubber and rear holder during crimping process.</li> <li>• Damage on crimp may affect the crimp resistance and retention force which may lead to product malfunction.</li> </ul> |                         |



## 2. Manufacturing process and inspection precautions

| No.               | 8                                                                                                                                                                                                                                                                                                                                         | RUBBER and REAR HOLDER Installation |
|-------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------|
| Production Method |  <p>Rubber insertion</p> <p>Rear holder insertion</p> <p>Rear Holder locked</p> <p>Figure 8</p>                                                                                                                                                         |                                     |
| Part Name         | RUBBER, REAR HOLDER                                                                                                                                                                                                                                                                                                                       |                                     |
| Equipment         | -                                                                                                                                                                                                                                                                                                                                         |                                     |
| Standard          | -                                                                                                                                                                                                                                                                                                                                         |                                     |
| Inspection Matter | <ul style="list-style-type: none"> <li>• There shall be no dust and other foreign object on the rubber before installation.</li> <li>• There shall be no damage on the sealing surface of housing before installation.</li> <li>• Ensure the locking of rear holder type A/C lock (2 Places) into housing. (Refer to figure 8)</li> </ul> |                                     |
| Precautions       | <ul style="list-style-type: none"> <li>• Care must be taken not to damage the rubber during installation, Damage on the rubber can lead to product malfunction.</li> </ul>                                                                                                                                                                |                                     |

### 3. The size of Insertion Tool










Figure 9

(the dimensions a,b refer to the size of wire)

#### 4. Power Terminal Removal and Precautions

| No.               | 1                                                                                                                                                                                                                                                                                                                                                                                                                  | Front Holder Full-lock Removal |
|-------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------|
| Production Method | <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  <p>Figure 10</p> </div> <div style="text-align: center;"> <p>THE SIZE OF REMOVAL TOOL</p>  <p>Figure 11</p> </div> </div> |                                |
| Part Name         | POWER FRONT HOLDER                                                                                                                                                                                                                                                                                                                                                                                                 |                                |
| Equipment         | -                                                                                                                                                                                                                                                                                                                                                                                                                  |                                |
| Standard          | -                                                                                                                                                                                                                                                                                                                                                                                                                  |                                |
| Inspection Matter | -                                                                                                                                                                                                                                                                                                                                                                                                                  |                                |
| Precautions       | <ul style="list-style-type: none"> <li>Disassembly is not recommended. Dedicated tools are required to install Power Front Holder .</li> <li>After disassembly and installation again, the retention force of Power Front Holder will decrease.</li> </ul>                                                                                                                                                         |                                |

## 4. Power Terminal Removal and Precautions

| No.               | 2                                                                                                                                                                                                                                                                                                                                                                                                                 | Terminal Removal                                                                   |                                                                                                                       |
|-------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------|
| Production Method |  <p>Remove rear holder</p> <p>Figure 12</p>  <p>Remove mat seal</p> <p>Figure 13</p>                                                                                                                                                            |  |  <p>Removal tool<br/>Figure 14</p> |
| Part Name         | POWER TERMINAL                                                                                                                                                                                                                                                                                                                                                                                                    |                                                                                    |                                                                                                                       |
| Equipment         | -                                                                                                                                                                                                                                                                                                                                                                                                                 |                                                                                    |                                                                                                                       |
| Standard          | -                                                                                                                                                                                                                                                                                                                                                                                                                 |                                                                                    |                                                                                                                       |
| Inspection Matter | <ul style="list-style-type: none"> <li>• The terminal removal operation should be performed by trained personnel only</li> <li>• Remove the rear holder and mat seal before terminal removal operation.</li> <li>• Insert the removal tool parallel to the cavity of the housing.<br/>The tip of tool must be positioned between the servicing tab of the flexible arm and the terminal.</li> </ul>               |                                                                                    |                                                                                                                       |
| Precautions       | <ul style="list-style-type: none"> <li>• Please be careful when disassembling. The Power lance will break during the disassembly process.</li> <li>• If the terminal does not disengage easily from the housing, repeat the steps previously outlined.</li> <li>• If any damage is visible on the terminal and/or housing, the affected component should be replaced, repairs should not be attempted.</li> </ul> |                                                                                    |                                                                                                                       |

| YGT19-0055 |                                                              | Handling manual for<br>HV 4.8 CONNECTOR 2P ASSEMBLY FEMALE<br>(SHORT TERMINAL VERSION) |        |            |              |
|------------|--------------------------------------------------------------|----------------------------------------------------------------------------------------|--------|------------|--------------|
| HISTORY    |                                                              |                                                                                        |        |            |              |
| DATE       | CONTENTS                                                     | App'd.                                                                                 | Chk'd. | Chk'd.     | Prep.        |
| 2019.8.14  | PRELIMINARY                                                  | Haijun.Chen                                                                            | -      | Lijuan.Fan | Lindi.Yang   |
| 2020.3.20  | Add Tolerance                                                | Haijun.Chen                                                                            |        | Lijuan.Fan | Haitong.Shen |
| 2020.5.25  | Power Terminal Installation<br>manufacturing process changed | Haijun.Chen                                                                            |        | Lijuan.Fan | Haitong.Shen |
| 2021.4.25  | Power Terminal Removal and<br>Signal Terminal Removal        | Haijun.Chen                                                                            | -      | Lijuan.Fan | Zhibin.Ren   |
|            |                                                              |                                                                                        |        |            |              |
|            |                                                              |                                                                                        |        |            |              |