

**YGT19-0057**

Non-related personnel Secrets

関係者外密

**Handling Manual**  
**for**  
**HV 4.8 CONNECTOR 2P**  
**HEADER MALE**

**<NOTE>**

Please be informed that the contents in this handling manual  
may be revised without notice.

YAZAKI (CHINA) INVESTMENT CO.,LTD






OCT. 10. 2020

This handling manual mentions the minimum items necessary on using this product.  
Please observe these written contents when handling.  
YAZAKI shall not be liable for any damages resulting from misuse or failure to follow this manual.




## Table of Contents

|                                                                                                                                               |       |      |
|-----------------------------------------------------------------------------------------------------------------------------------------------|-------|------|
| 1. Components part list                                                                                                                       | ..... | P.3  |
| 2. Manufacturing process and inspection precautions                                                                                           |       |      |
| No. 1 Wire Insulation Stripping                                                                                                               | ..... | P.4  |
| No. 2 Power Terminal Crimping                                                                                                                 | ..... | P.5  |
| No. 3 Signal Terminal Crimping                                                                                                                | ..... | P.6  |
| No. 4 Signal Terminal Installation and Front Holder Setting                                                                                   | ..... | P.7  |
| No. 5 Power Terminal Installation and Front Holder Setting                                                                                    | ..... | P.8  |
| No. 6 Rear Holder Installation                                                                                                                | ..... | P.9  |
|  No. 7 4.8 Connector Header Assy Installation Into Vehicle | ..... | P.10 |


## 1. Components Part List

| No. | Part Name                                                                                                                                                    | Part No                                      | Image Form                                                                            | Function                          |
|-----|--------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------|---------------------------------------------------------------------------------------|-----------------------------------|
| 1   | HV 4.8 CONNECTOR 2P<br>HEADER HOUSING MALE<br>SUB ASSEMBLY (M4/M5<br>SPEC.)                                                                                  | 7285-1215-51<br>7285-1216-51<br>7285-1217-51 |    | TERMINAL RETENTION                |
| 2   | RH TYPE TERMINAL FEMALE                                                                                                                                      | 7116-4416-02                                 |    | CONNECTION OF ELECTRIC CIRCUIT    |
| 3   | HV 4.8 CONNECTOR 2P<br>TERMINAL MALE                                                                                                                         | 7185-0905-02                                 |    | CONNECTION OF ELECTRIC CIRCUIT    |
| 4   | HV 4.8 CONNECTOR 2P<br>HEADER REAR HOLDER<br>MALE                                                                                                            | 7185-0795                                    |   | PREVENTS WIRE SEAL FROM DETACHING |
| 5   | <br>HV 4.8 CONNECTOR 2P<br>HEADER HOUSING MALE<br>SUB ASSEMBLY (M4 SPEC.) | 7285-1962-51<br>7285-1963-51<br>7285-1964-51 |  | TERMINAL RETENTION                |


## 2. Manufacturing process and inspection precautions

| No.               | 1                                                                                                                                                                                                                                                                          | WIRE Insulation Stripping                                                           |
|-------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|
| Production Method |  <p>5.45mm(REF)</p> <p>Power Wire<br/>Figure 1</p>  <p>4.00mm(REF)</p> <p>Signal wire<br/>Figure 2</p> |  |
| Part Name         | Power Wire, Signal Wire                                                                                                                                                                                                                                                    |                                                                                     |
| Equipment         |                                                                                                                                                                                                                                                                            |                                                                                     |
| Standard          | Insulation Strip dimension: <ul style="list-style-type: none"> <li>• Power : 5.45mm (Refer to figure 1)</li> <li>• Signal : 4.00 (Refer to figure 2)</li> </ul>                                                                                                            |                                                                                     |
| Inspection Matter | <ul style="list-style-type: none"> <li>• Insulation strip must be free from any damage.</li> </ul>                                                                                                                                                                         |                                                                                     |
| Precautions       | <ul style="list-style-type: none"> <li>• Damage in wire strip can cause increase in crimp resistance which may lead to product malfunction.</li> </ul>                                                                                                                     |                                                                                     |



## 2. Manufacturing process and inspection precautions

| No.               | 2                                                                                                                                                                                                                                         | POWER TERMINAL Crimping |
|-------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------|
| Production Method |                                                                                                                                                         |                         |
| Part Name         | TERMINAL MALE                                                                                                                                                                                                                             |                         |
| Equipment         |                                                                                                                                                                                                                                           |                         |
| Standard          | Crimping Standard (Refer to YGT19-0054)                                                                                                                                                                                                   |                         |
| Inspection Matter | <ul style="list-style-type: none"><li>▪ After crimping there should be no damage on the terminal male.</li><li>▪ No burr after crimping.</li><li>▪ No deformation after crimping.</li></ul>                                               |                         |
| Precautions       | <ul style="list-style-type: none"><li>▪ Care must be taken not to damage the wire during crimping process.</li><li>▪ Damage on crimp may affect the crimp resistance and retention force which may lead to product malfunction.</li></ul> |                         |




## 2. Manufacturing process and inspection precautions

| No.               | 3                                                                                                                                                                                                                                            | SIGNAL TERMINAL Crimping |
|-------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------|
| Production Method |                                                                                                                                                            |                          |
| Part Name         | RH TYPE TERMINAL FEMALE                                                                                                                                                                                                                      |                          |
| Equipment         |                                                                                                                                                                                                                                              |                          |
| Standard          | Crimping Standard (Refer to YGT19-0054)                                                                                                                                                                                                      |                          |
| Inspection Matter | <ul style="list-style-type: none"> <li>▪ After crimping there should be no damage on the RH type terminal female.</li> <li>▪ No burr after crimping.</li> <li>▪ No deformation after crimping.</li> </ul>                                    |                          |
| Precautions       | <ul style="list-style-type: none"> <li>▪ Care must be taken not to damage the wire during crimping process.</li> <li>▪ Damage on crimp may affect the crimp resistance and retention force which may lead to product malfunction.</li> </ul> |                          |


## 2. Manufacturing process and inspection precautions

| No.               | 4                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            | SIGNAL TERMINAL Installation and FRONT HOLDER Setting                                                                                                                             |
|-------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Production Method |  <p>Signal terminal orientation<br/>Figure 4</p>                                                                                                                                                                                                                                                                                                                                                                                                            |  <p>Insertion direction</p> <p>Front holder</p> <p>Front Holder fully engaged<br/>Figure 3</p> |
| Part Name         | RH TYPE TERMINAL FEMALE                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |                                                                                                                                                                                   |
| Equipment         | -                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |                                                                                                                                                                                   |
| Standard          | -                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |                                                                                                                                                                                   |
| Inspection Matter | <ul style="list-style-type: none"> <li>• The front holder male must be in the pre-set position prior to the installation of terminals.</li> <li>• Ensure that RH type terminal female was locked to the housing lance.</li> <li>• There shall be no defects or deformation on front holder male before assembly.</li> <li>• After installation of all applicable terminals, the front holder male must be moved to the full-lock position. (Refer to figure 3)</li> </ul>                                                                    |                                                                                                                                                                                   |
| Precautions       | <ul style="list-style-type: none"> <li>• Observe the proper orientation of RH type terminal female before assembly. (Refer to figure 4)</li> <li>• Insert the RH type terminal female until CLICK sound was heard.</li> <li>• After inserting the terminal, pull the wire lightly to verify the terminal is locked.</li> <li>• Do not bend the front holder male lock before assembly.</li> <li>• If the front holder male is not pushed into the full-lock position smoothly, the terminal may not have been inserted correctly.</li> </ul> |                                                                                                                                                                                   |

## 2. Manufacturing process and inspection precautions

| No.               | 5                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          | POWER TERMINAL Installation and FRONT HOLDER Setting                                                                                                                                          |                                                                                                                                                                                                                        |
|-------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Production Method |  <p data-bbox="526 683 703 774">Power Terminal<br/>orientation<br/>Figure 6</p>                                                                                                                                                                                                                                                                                                                                                           |  <p data-bbox="1153 375 1346 399">Insertion direction</p> <p data-bbox="1317 651 1473 675">No wire bend</p> |  <p data-bbox="1727 263 1877 287">Front holder</p> <p data-bbox="1691 662 1877 758">Front holder Fully<br/>engaged<br/>Figure 5</p> |
| Part Name         | TERMINAL MALE                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |                                                                                                                                                                                               |                                                                                                                                                                                                                        |
| Equipment         | -                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |                                                                                                                                                                                               |                                                                                                                                                                                                                        |
| Standard          | -                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |                                                                                                                                                                                               |                                                                                                                                                                                                                        |
| Inspection Matter | <ul style="list-style-type: none"> <li>• The power front holder must be in the pre-set position prior to the installation of terminals.</li> <li>• Ensure that terminal male was locked to the housing lance.</li> <li>• There shall be no defects or deformation on power front holder before assembly.</li> <li>• After installation of all applicable terminals, the power front holder must be moved to the full-lock position. (Refer to figure 5)</li> </ul>                                                         |                                                                                                                                                                                               |                                                                                                                                                                                                                        |
| Precautions       | <ul style="list-style-type: none"> <li>• Observe the proper orientation of terminal male before assembly. (Refer to figure 6)</li> <li>• Insert the terminal male until CLICK sound was heard.</li> <li>• After inserting the terminal, pull the wire lightly to verify the terminal is locked.</li> <li>• Do not bend the power front holder lock before assembly.</li> <li>• If the power front holder is not pushed into the full-lock position smoothly, the terminal may not have been inserted correctly.</li> </ul> |                                                                                                                                                                                               |                                                                                                                                                                                                                        |

## 2. Manufacturing process and inspection precautions

| No.               | 6                                                                                                                                                                                                                            | REAR HOLDER Installation |
|-------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------|
| Production Method |  <p>Insertion direction</p> <p>17.40mm(REF)</p> <p>Rear Holder Locked</p> <p>Figure 7</p>                                                  |                          |
| Part Name         | REAR HOLDER MALE                                                                                                                                                                                                             |                          |
| Equipment         | -                                                                                                                                                                                                                            |                          |
| Standard          | -                                                                                                                                                                                                                            |                          |
| Inspection Matter | <ul style="list-style-type: none"><li>▪ Ensure the locking of rear holder lock (4 Places) into housing male. (Refer to figure 7)</li></ul>                                                                                   |                          |
| Precautions       | <ul style="list-style-type: none"><li>▪ Care must be taken not to damage the rear holder male lock (4 places) during installation, Damage on the rear holder male lock (4 places) can lead to product malfunction.</li></ul> |                          |



|            | Handling manual for<br>HV 4.8 CONNECTOR 2P<br>HEADER MALE                                          | YGT19-0057  |        |            |               |
|------------|----------------------------------------------------------------------------------------------------|-------------|--------|------------|---------------|
|            | HISTORY                                                                                            |             |        |            |               |
| DATE       | CONTENTS                                                                                           | App'd.      | Chk'd. | Chk'd.     | Prep.         |
| 2019.8.14  | PRELIMINARY                                                                                        | Haijun.Chen | -      | Lijuan.Fan | Lindi.Yang    |
| 2020.7.13  | ADD THE MANANUFACTURING PROCESS<br>4.8 CONNECTOR HEADER ASSY INSTALLATION                          | Haijun.Chen | -      | Lijuan.Fan | Haitong.Shen  |
| 2020.10.10 | CHANGE THE INSPECTION MATTER FOR<br>4.8 CONNECTOR HEADER ASSY INSTALLATION                         | Haijun.Chen | -      | Lijuan.Fan | Haitong.Shen  |
| 2023.01.29 |  ADD HEADER TYPE | Haijun.Chen | -      | Lijuan.Fan | Guoqiang.Wang |
|            |                                                                                                    |             |        |            |               |
|            |                                                                                                    |             |        |            |               |

## 2. 製造工程及び確認事項

| No.                                                                                                                         | 7                         | 4.8 Connector Header 設備側への組付け                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
|-----------------------------------------------------------------------------------------------------------------------------|---------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <div data-bbox="264 304 338 357" data-label="Text">1</div> <div data-bbox="248 507 383 539" data-label="Text">組付け方法</div>   |                           | <div data-bbox="416 268 1050 743" data-label="Image"> </div> <div data-bbox="568 759 672 791" data-label="Caption">Figure 8</div> <div data-bbox="1077 268 1637 775" data-label="Image"> </div> <div data-bbox="1211 767 1314 799" data-label="Caption">Figure 9</div> <div data-bbox="1592 389 2040 695" data-label="Image"> </div> <div data-bbox="1760 703 1886 735" data-label="Caption">Figure 10</div>                                                                                                                                                                                                      |
| 部品名                                                                                                                         | 4.8 CONNECTOR HEADER ASSY |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| 設備                                                                                                                          | -                         |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| 規格                                                                                                                          | -                         |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| <div data-bbox="264 995 338 1048" data-label="Text">2</div> <div data-bbox="248 1118 383 1150" data-label="Text">検査項目</div> |                           | <div data-bbox="398 927 1003 1350" data-label="List-Group"> <p>STEP 1: コネクタ挿入時</p> <ul style="list-style-type: none"> <li>・コネクタを垂直に奥まで挿入すること。</li> </ul> <p>STEP 2: コネクタ挿入完了時</p> <ul style="list-style-type: none"> <li>・コネクタにパッキン以外の外力が掛かっていない状態であること。</li> <li>・コネクタが垂直になっていること。</li> <li>・カラー穴からねじ穴が完全に見えること。</li> </ul> <p>STEP 3: コネクタ仮止め</p> <ul style="list-style-type: none"> <li>・上記状態で、コネクタが動かないように仮締めすること。</li> </ul> <p>STEP4: コネクタ本締め</p> <ul style="list-style-type: none"> <li>・本締め時には、コネクタがずれないようにすること。</li> <li>・ゴムパッキンは設備側に傷つけていないこと。(図8を参照)</li> <li>・推奨トルク: 1.35~2.00 N・m。</li> </ul> </div> |
| 注意事項                                                                                                                        |                           | <div data-bbox="398 1390 1469 1493" data-label="List-Group"> <ul style="list-style-type: none"> <li>・設備側間口形状はR図に参照すること。</li> <li>・ゴムパッキンの有無、ボカヨケピン孔が正しい位置にある事を確認してからコネクタを設備側間口に挿入すること。</li> <li>・設備側締め付けタブの有無を確認し、M4ボルトを組付け、仮締めしてから本締めをすること。</li> </ul> </div>                                                                                                                                                                                                                                                                                                                                                    |